A. ALL PENETRATIONS IN FIRE RATED WALLS ARE TO BE SEALED AND FIRE STOPPED BY A U.L. LISTED FIRE ASSEMPLY AND APPROVED MANNER B. REFER TO ARCHITECT'S CASEWORK/FURNITURE DETAILS AND ROOM ELEVATIONS FOR EXACT LOCATION AND MOUNTING HEIGHTS OF DEVICES, ETC. C. PROVIDE PULL WIRES IN EACH EMPTY CONDUIT LEFT FOR FURNITURE USE. D. ALL WIRING SHALL BE #12 WITH A #12 GROUND (U.O.N.).

of

Studi

E4.3